



> EXTRACTEURS DE GOUPILLES ET DE CLAVETTES TARAUDÉES

THREADED DOWEL PINS EXTRACTOR

SUR QUELLES PIÈCES L'UTILISER ?

Goupilles : DIN 7979,
 DIN 7978,
 ISO 8735,
 ISO 8736 de 5 à 20 mm.

Vis d'extraction : de M3 à M10.

Clavettes : DIN 6885 E,
 DIN 6885 F,
 NFE 22181.

POUR QUELS UTILISATEURS ?

- Techniciens monteur.
- Techniciens de maintenance.

COMMENT UTILISER L'OUTIL ?

- 1 Visser à l'axe de l'extracteur le goujon approprié en fonction du taraudage de la goupille.
- 2 Visser l'ensemble outil/goujon sur la goupille.
- 3 Il suffit de frapper la masselote contre la tête de l'extracteur pour que la goupille sorte de son logement.

ON WHICH PINS TO USE IT ?

Pins : DIN 7979,
 DIN 7978,
 ISO 8735,
 ISO 8736 de 5 à 20 mm.

Knockout screws : de M3 à M10.

Keys : DIN 6885 E,
 DIN 6885 F,
 NFE 22181.

FOR WHICH USERS ?

- Assembly technician,
- Service Engineer.

HOW TO USE THIS TOOLS ?

- 1 Choose a stud adapted to the tapping of the pin and screw it onto the extractor axis.
- 2 Screw this unit onto the pin.
- 3 Hit the counter weight against the head of extractor so that the pin ejects.

